



Verilog HDL QUICK REFERENCE CARD

Revision 2.1

()	Grouping	[]	Optional
{}	Repeated		Alternative
bold	As is	CAPS	User Identifier

1. MODULE

```
module MODID[{{PORTID,}}];
  [input | output | inout [range] {PORTID,};]
  [{declaration}]
  [{parallel_statement}]
  [specify_block]
endmodule

range ::= [constexpr : constexpr]
```

2. DECLARATIONS

```
parameter {PARID = constexpr,};
wire | wand | wor [range] {WIRID,};
reg [range] {REGID [range,]};
integer {INTID [range,]};
time {TIMID [range,]};
real {REALID,};
realtime {REALTIMID,};
event {EVTID,};
task TASKID;
  [{input | output | inout [range] {ARGID,};}]
  [{declaration}]
begin
  [{sequential_statement}]
end
endtask

function [range] FCTID;
  {input [range] {ARGID,};}
  [{declaration}]
begin
  [{sequential_statement}]
end
endfunction
```

© 1995-1998 Qualis Design Corporation

3. PARALLEL STATEMENTS

```
assign [(strength1, strength0)] WIRID = expr;
initial sequential_statement
always sequential_statement
MODID [#({expr,})] INSTID
  ({expr,} | .PORTID(expr,));
GATEID [(strength1, strength0)] [#delay]
  [INSTID] (expr,);
defparam {HIERID = constexpr,};
strength ::= supply | strong | pull | weak | highz
delay ::= number | PARID | ( expr [, expr [, expr]] )
```

4. GATE PRIMITIVES

and (out, in ₁ , ..., in _N);	nand (out, in ₁ , ..., in _N);
or (out, in ₁ , ..., in _N);	nor (out, in ₁ , ..., in _N);
xor (out, in ₁ , ..., in _N);	xnor (out, in ₁ , ..., in _N);
buf (out ₁ , ..., out _N , in);	not (out ₁ , ..., out _N , in);
bufif0 (out, in, ctl);	bufif1 (out, in, ctl);
notif0 (out, in, ctl);	notif1 (out, in, ctl);
pullup (out);	pulldown (out);
[r]pmos (out, in, ctl);	
[r]nmos (out, in, ctl);	
[r]cmos (out, in, nctl, pctl);	
[r]tran (inout, inout);	
[r]tranif1 (inout, inout, ctl);	
[r]tranif0 (inout, inout, ctl);	

5. SEQUENTIAL STATEMENTS

```
;

begin[: BLKID
  [{declaration}]
  [{sequential_statement}]
end

if (expr) sequential_statement
[else sequential_statement]
case | casex | casez (expr)
  [{expr,}: sequential_statement]
  [default: sequential_statement]
endcase

forever sequential_statement
repeat (expr) sequential_statement
while (expr) sequential_statement
for (lvalue = expr; expr; lvalue = expr)
  sequential_statement
#(number | (expr)) sequential_statement
@ (event [or event]) sequential_statement
lvalue [<]= #[(number | (expr))] expr;
lvalue [<]= @ (event [or event])) expr;
```

© 1995-1998 Qualis Design Corporation

```
wait (expr) sequential_statement
-> EVENTID;
fork[: BLKID
  [{declaration}]
  [{sequential_statement}]
join
TASKID[({expr,})];
disable BLKID | TASKID;
assign lvalue = expr;
deassign lvalue;
lvalue ::= ID[range] | ID[expr] | {{lvalue,}}
event ::= [posedge | negedge] expr
```

6. SPECIFY BLOCK

```
specify_block ::= specify
  {specify_statement}
  endspecify
```

6.1. SPECIFY BLOCK STATEMENTS

```
specparam {ID = constexpr,};
(terminal => terminal) = path_delay;
((terminal,) * > {terminal,}) = path_delay;
if (expr) (terminal [+|-]> terminal) = path_delay;
if (expr) ({terminal,} [+|-]*> {terminal,}) =
  path_delay;
[if (expr)] ([posedge|negedge] terminal =>
  (terminal [+|-]: expr)) = path_delay;
[if (expr)] ([posedge|negedge] terminal *>
  ({terminal,} [+|-]: expr)) = path_delay;
$setup(tevent, tevent, expr [, ID]);
$hold(tevent, tevent, expr [, ID]);
$setuphold(tevent, tevent, expr, expr [, ID]);
$period(tevent, expr [, ID]);
$width(tevent, expr, constexpr [, ID]);
$skew(tevent, tevent, expr [, ID]);
$recovery(tevent, tevent, expr [, ID]);
tevent ::= [posedge | negedge] terminal
  [&&& scalar_expr]
path_delay ::= expr | (expr, expr [, expr [, expr, expr, expr]])
```

terminal ::= ID[range] | ID[expr]

© 1995-1998 Qualis Design Corporation. Permission to reproduce and distribute strictly verbatim copies of this document in whole is hereby granted.

See reverse side for additional information.

7. EXPRESSIONS

primary
 unop primary
 expr binop expr
 expr ? expr : expr
 primary ::=
 literal | value | FCTID({expr,}) | (expr)

7.1. UNARY OPERATORS

+, -	Positive, Negative
!	Logical negation
~	Bitwise negation
&, ~&	Bitwise and, nand
, ~	Bitwise or, nor
^, ~^, ^~	Bitwise xor, xnor

7.2. BINARY OPERATORS

Increasing precedence:

?:	if/else
	Logical or
&&	Logical and
	Bitwise or
^, ^~	Bitwise xor, xnor
&	Bitwise and
==, !=, ===, !==	Equality
<, <=, >, >=	Inequality
<<, >>	Logical shift
+, -	Addition, Subtraction
*, /, %	Multiply, Divide, Modulo

7.3. SIZES OF EXPRESSIONS

unsized constant	32
sized constant	as specified
i op j	+,-,*/,%,&, ^,^~
op i	+, -, ~
i op j	==, !=, ==, !=
	&&, , >, >=, <, <=
op i	&, ~&, , ~ , ^, ^~
i op j	>>, <<
i ? j : k	
{i,...j}	max(L(j), L(k))
{i(j,...k)}	L(i) + ... + L(j)
i = j	i * (L(j)+...+L(k))
	L(i)

8. SYSTEM TASKS

* indicates tasks not part of the IEEE standard but mentioned in the informative appendix.

8.1. INPUT

\$readmemb("fname", ID [, startadd [, stopadd]]);
 \$readmemh("fname", ID [, startadd [, stopadd]]);
 **\$sreadmemb(ID, startadd, stopadd {, string});
 **\$sreadmemh(ID, startadd, stopadd {, string});

8.2. OUTPUT

\$display[defbase]([fmtstr,] {expr,});
 \$write[defbase] ([fmtstr,] {expr,});
 \$strobe[defbase] ([fmtstr,] {expr,});
 \$monitor[defbase] ([fmtstr,] {expr,});
 \$fdisplay[defbase] (fileno, [fmtstr,] {expr,});
 \$fwrite[defbase] (fileno, [fmtstr,] {expr,});
 \$fstrobe(fileno, [fmtstr,] {expr,});
 \$fmonitor(fileno, [fmtstr,] {expr,});
 fileno = \$open("filename");
 \$fclose(fileno);
 defbase ::= h | b | o

8.3. TIME

\$time	"now" as TIME
\$stime	"now" as INTEGER
\$realtime	"now" as REAL
\$scale(hierid)	Scale "foreign" time value
\$printtimescale([path])	Display time unit & precision
\$timeformat(unit#, prec#, "unit", minwidth)	Set time % display format

8.4. SIMULATION CONTROL

\$stop	Interrupt
\$finish	Terminate
*\$save("fn")	Save current simulation
*\$incsave("fn")	Delta-save since last save
*\$restart("fn")	Restart with saved simulation
*\$input("fn")	Read commands from file
*\$log("fn")]	Enable output logging to file
*\$nolog	Disable output logging
*\$key("fn")]	Enable input logging to file
*\$nokey	Disable input logging
*\$scope(hiername)	Set scope to hierarchy
*\$showscopes	Scopes at current scope
*\$showscopes(1)	All scopes at & below scope
*\$showvars	Info on all variables in scope
*\$showvars(ID)	Info on specified variable
*\$countdrivers(net)>1	driver predicate
*\$list([ID])	List source of [named] block
\$monitor	Enable \$monitor task
\$monitoroff	Disable \$monitor task
\$dumpon	Enable val change dumping
\$dumpoff	Disable val change dumping
\$dumpfile("fn")	Name of dump file
\$dumplimit(size)	Max size of dump file
\$dumpflush	Flush dump file buffer
\$dumpvars(levels {[, MODID VARID]})	Variables to dump
\$dumpall	Force a dump now
*\$reset(0)	Reset simulation to time 0
*\$reset(1)	Reset and run again
*\$reset(0 1, expr)	Reset with reset_value
*\$reset_value	Reset_value of last \$reset
*\$reset_count	# of times \$reset was used

8.5. MISCELLANEOUS

\$random([ID])	
*\$getpattern(mem)	Assign mem content
\$rtoi(expr)	Convert real to integer
\$itor(expr)	Convert integer to real
\$realtobits(expr)	Convert real to 64-bit vector
\$bitstoreal(expr)	Convert 64-bit vector to real

8.6. ESCAPE SEQUENCES IN FORMAT STRINGS

\n, \t, \\", \\	newline, TAB, '\', ''
\xxx	character as octal value
%%	character '%'
%[w.d]e, %[w.d]E	display real in scientific form
%[w.d]f, %[w.d]F	display real in decimal form
%[w.d]g, %[w.d]G	display real in shortest form
%[0]h, %[0]H	display in hexadecimal
%[0]d, %[0]D	display in decimal
%[0]o, %[0]O	display in octal
%[0]b, %[0]B	display in binary
%[0]c, %[0]C	display as ASCII character
%[0]v, %[0]V	display net signal strength
%[0]s, %[0]S	display as string
%[0]t, %[0]T	display in current time format
%[0]m, %[0]M	display hierarchical name

9. LEXICAL ELEMENTS

hierarchical identifier ::=	{INSTID .} identifier
identifier ::=	letter _ { alphanumeric \$ _ }
escaped identifier ::=	\{nonwhite\}
decimal literal ::=	[+-]integer [. integer] [E e[+-]integer]
based literal ::=	integer ' base {hexdigit x z}
base ::=	b o d h
comment ::=	// comment newline
comment block ::=	/* comment */

© 1995-1998 Qualis Design Corporation. Permission to reproduce and distribute strictly verbatim copies of this document in whole is hereby granted.

Qualis Design Corporation
Elite Consulting and Training in High-Level Design

Phone: +1-503-670-7200 FAX: +1-503-670-0809

E-mail: info@qualis.com com

Web: http://www.qualis.com

Also available: VHDL Quick Reference Card
 1164 Packages Quick Reference Card